

**CHEM LINK Products LLC**

Telephone: 800-826-1681  
Fax: 269-679-4448  
353 East Lyons  
Schoolcraft, MI 49087  
www.chemlinkinc.com

Last Revision: 03/15/11

**Product Description:**

The CHEM LINK **Solar Shoe LS** provides an economical, yet innovative solution to mounting solar panels on shingled and low slope roofs. The **Solar Shoe LS** is made from a high strength thermal setting polyurethane that can resist heavy impact at high and low temperatures.

**Installation Instructions:**

1. Determine the installation location.
2. Clean installation location with alcohol. (Do not use petroleum based solvent!)
3. Apply **M-1**<sup>®</sup> to base surface.
4. Position Solar **Shoe LS** and press firmly to set with **M-1**<sup>®</sup>.
5. Utilize the **M-1**<sup>®</sup> "squeeze-out" to form a fillet around the base perimeter.
6. Install two 1/4 x 3" lag bolts or screws through apertures on opposite ends of the **Solar Shoe LS**.
7. Clean area using alcohol.
8. Install attaching hardware.

Document CLP 124



**Features and Advantages:**

- Installation of the CHEM LINK **Solar Shoe LS** is quick and easy with **M-1**<sup>®</sup> adhesive/sealant.
- When properly installed, the **Solar Shoe LS** provides 2" of clearance between the solar panel and roof.
- The elastomeric properties of **M-1**<sup>®</sup> adhesive/sealant provide vibration absorption to the solar panel assembly.
- Installation possible on new and existing shingle and low slope roofing surfaces.

